


LEFT HAND CONTROLLER COMPONENTS:
PITCH AND MOD WHEELS
NOT ON LEFT FRONT PANEL PCB



Note: The pitch wheel wires are reversed from the mod wheel. On my unit, I had to rotate the pitch wheel potentiometer some to make it work properly. Possibly the trimmer on the left front panel board could have been used instead, but I am not sure.

